

IMPORTANT SET-UP INFORMATION

Connecting **Mi-30s** to your SMART TV and **Sound Bar**.

You can use the following methods to connect your Smart TV to your Sound Bar.

SMART TV > **Mi-30s** > **Sound Bar**

1. Bluetooth > **Mi-30s** (then **Optical Output**) > **Sound Bar** (Optical Input)
2. Bluetooth > **Mi-30s** (then **AUX Output**) > **Sound Bar** (AUX Input)
3. HDMI ARC > **Mi-30s** (then **AUX Output**) > **Sound Bar** (AUX Input)
4. Optical Output > **Mi-30s** (then **AUX Output**) > **Sound Bar** (AUX Input)
5. Headphone Jack (3.5mm Line Cable) > **Mi-30s** (then **AUX Output**) > **Sound Bar** (AUX Input)
6. Headphone Jack (3.5mm Line Cable) > **Mi-30s** (then **Optical Output**) > **Sound Bar** (Optical Input)

TIP 1: If you are using HDMI ARC with your Sound Bar for normal TV viewing then please disconnect the HDMI ARC cable from the Sound Bar, as the HDMI Cable is the dominate connection and will override the Optical Input (not even see it) if the HDMI is plugged in.

You might need to turn the sound bar off and back on once done to reset it. Some sound bars have the option to select the input, but you still might need to unplug the HDMI cable.

7. Optical Output > into **DAC** then > **Mi-30s** (then **AUX input**) > **Sound Bar** (Optical Input)

Using your TV's Optical Out and Sound Bars Optical Input with the Mi-30s Mixer can only be achieved by using a DAC Converter which will take the Optical Out and Convert it to Analog so you can input the sound into the Mi-30s via AUX input and then take it out via Optical Output into the Sound Bars Optical Input. **(OPTIONAL DAC CONVERTER PICTURED BELOW)**

www.khe.com.au/DAC



TIP 2: Bluetooth connectivity with Mi-30s is the default mode for the Mi-30s you need to push the MODE button to select other inputs like AUX or Optical/HDMI ARC and each time you will hear from your speakers it say the mode i.e. Bluetooth Mode, AUX Mode etc. **(also see Final TIP)**

You can use Bluetooth to connect any Bluetooth device i.e. Smart TV, Phone, Tablet or Laptop to stream the audio through the Mi-30s mixer.

TIP 3: AUX Input on your Sound Bar/Sound System can be either Line Input (3.5mm Cable) or RCA (Red/White) Cable. Both are included in the box with the Mi-30s.

TIP 4: TV Settings, make sure if using either HDMI ARC or Optical Output that your TV's Sound Settings are set to Optical/Digital Output sometimes also called SPDIF and that the sound method selected is PCM Audio.

When this is selected the TV's speakers will no longer be operational as the sound will be channelled to output via either the HDMI ARC or Optical Output to the Mi-30s.

If the sound is still coming from your TV, then it's not set-up correctly for either HDMI ARC or Optical Output.

FINAL TIP: Connecting the audio output (AUX or Optical) from the Mi-30s to your Sound Bar or any Sound System (i.e. Hi-Fi System, Home Theatre System, Powered Speaker etc.) should be the second connection point you make after the connecting the power to the Mi-30s.



Once power is connected and you have connected your sound system and you TURN On the Mi-30s you will hear through your sound system speakers the Mi-30s say on boot-up “Bluetooth Mode” and if you then push the MODE BUTTON on the Mi-30s it will then say “AUX Mode, Optical Mode etc) with each push.

If you don't hear this then you are not yet connected correctly to your sound system, also the microphones should be working at this point.

Don't try to connect any other device like your Smart TV, Phone or Tablet etc (for the Audio/Music) until this part works.

If you still require assistance after trying these solutions please call Tim on 1300 550 630 / 0403 927 371 During Business Hours (Monday to Friday) or email info@khe.com.au

Thank you
Tim.

* PSU from a mobile phone charger for example can be used.